

Motive Lab

All Weather Climatic Chamber and Chassis Dynamometer Test Facility

Vehicle Technology International Conference
Winnipeg, Manitoba
Oct 2, 2019

Kevin Dickson, P. Eng.
Vehicle Technology Research Professional

Project Charter





MotiveLab™

- MotiveLab is a 7000 sq. ft. Climatic and Integrated Dynamometer testing facility located at Red River College's Notre Dame Campus, co-located in the Vehicle Technology Research Centre.
- Capable of accommodating large vehicles , E.g. on-highway coach. Overall Chamber room size: 61' Deep, 21' Wide , 17' high. Main Door Size: 13' Wide 14' 7" high
- Two main modes of operation – Closed loop and Open loop

MotiveLab™ - Thermal

- MotiveLab has thermal capability of producing a chamber temperature range of -40°C to 50°C ($\pm 1^{\circ}\text{C}$) year round.
- In a Static operation (i.e. no additional heat being generated) the temperature can be maintained indefinitely.
- In a Dynamic operation the Chamber can maintain -40°C for up to 15 minutes under a 650 hp load (1.63 M BTU's).







Outside Winnipeg Temperature June 20th - 28°C


Thermal Equipment Facts

- Low Temperature Chiller:
 - Operating Weight – 34,000 lbs.
 - Size – 247 Tons (Average Home A/C – 2.0 Tons)
 - Refrigerant – RG - 507 (4800 lbs.)
- Brine Tanks:
 - Full Weight – 135,000 lbs. (each)
 - Capacity – 33,000 Liters (each) - Dynalene HC-50
 - Height – 30'
- Main Chamber Fan:
 - Rating - 125 HP
 - Weight – 10,300 lbs.
 - “Wind Effect” – creates 50km/h at full speed within the Chamber
- Main Brine Pumps:
 - Flow Rate – Max 95l/s
 - 100 HP
- Vehicle Exhaust Fan
 - 100 HP
 - Flow Rate – 23731 CFM




Main Chamber Fan

One of 2 Brine Storage Tanks





Make-Up Air Unit



Chamber PLC Control Rack



Main Low Temperature Chiller


MotiveLab™ - Chassis Dynamometer

- Integral 3 Axle Chassis Dynamometer, 2 Stationary Axles (Tandem Axle Configuration), one adjustable.
- Capable of 650 HP continuous (to the Rollers) with up to 1800 HP for short durations (E.g. To produce a Torque Curve) .
- Regenerative AC motors, resulting in fast response times and ground topology simulation.


Dynamometer Equipment Facts

- Dynamometer Weight Capacity:
 - Maximum Axle Weight: 30, 000 lbs./Axle
- Axle Spacing:
 - Width: 95" Outside dimension – all three Roller sets
 - Tandem Axles (Center to Center Roller Spacing): 62"
 - Adjustable Axle (Center to Inner Tandem Rollers): 102" to 133"
- AC Regeneration:
 - Dynamometer has the capacity to Regenerate enough Power to run the Dynamometer and Cooling system with minimum Utility Power Draw.
- Resistor Load Bank:
 - Continuous 1.25M BTU's load dissipation capacity


Dynamometer Roller Configuration (Fully Retracted)




Dynamometer Roller Configuration – Extended



Sample Screenshot for Dynamometer Control



Terrain Profile Example








Resistive Load Bank

Dynamometer and Chamber
Power Control Racks



MotiveLab Control Room



Additional Opportunities

- Given the large capacity of the Chamber there have been several other opportunities outside of Heavy Vehicle testing. Some examples include:
 - Validation of Large Stationary Equipment that is required to operate over a wide temperature range.
 - Personal Mobility testing and Equipment functionality – E.g. First responders with all the gear they need to carry in all temperatures.
 - Film Industry – when requiring consistent and secure sets.

Typical Tests

With the ability to reproduce temperature and terrain profiles, iterative design changes can be validated.

Some Typical testing scenarios could include:

- HVAC Verification on Transit and On-Highway Coaches (Drawn Down/Up Testing)
- Emissions Testing.
- Range Tests (Diesel and Electric)

